The blue box that tests. And tests.

Hipot Tester HT-2000S, HT-2800S, HT-3000S, HT-4200S

PN:00-HT2000S, 00-HT2800S, 00-HT3000S, 00-HT4200S

Dielectric Withstand / Adjustable Ground Continuity Tester.



The UL Listed HT-S series hipot now comes with an adjustable ground continuity test in range of 0.08- 1.50Ω , and Auto-offset for test leads up to 1.00Ω , adjustable voltage output, voltage ramp and leakage current.

Easy to use and connect. Ships complete with cables, manual, Calibration Certificate and Calibration Data Log Copy.

*Actual products may vary depending on options and configuration.

Features

- UL and c-UL approved.
- · Fast accurate results.
- Microcontroller Technologies.
- One button test, easy to setup.
- LED's indicate test progress.
- Upon failure, the buzzer sounds, and testing is terminated.
- Output voltage, leakage limit, volt ramp-up time, test duration and ground settings are controlled from rear panel.
- Adjustable Ground Continuity.
- Ground continuity test is defeatable for testing of two wire products.
- NEMA 5-15R receptacle provided on front panel for high voltage output.

- Can be connected to the GF-30AC-T ground bond tester for complete TUV and European safety testing, with the TESTLINK option.
- Supports PLC interface for complete automated testing with the RI option.
- Ergonomically designed for safety, speed, and efficiency.
- Rugged construction that can withstand a 6" drop with no damage.
- Small footprint and lightweight.
- Leads, manual and calibration certificate included.
- ISO17025 Calibration available.
- One year calibration cycle.
- One year warranty.



COMPLIANCE WEST USA

The blue box that tests. And tests.

Specifications

TESTING CIRCUITRY

HT-2000S

Test Type: AC. Max. Output Voltage: 2000Vac.

Leakage Current: 1-20mAac, 0.1mA increments.

HT-2800S

Test Type: DC.
Max. Output Voltage: 2800Vdc.

Leakage Current: 1-5mAdc, 0.1mA increments.

HT-3000S

Test Type: AC/DC.

Max. Output Voltage: 2000Vac / 2800Vdc.

Leakage Current: 1-20mAac / 1-5mAdc, 0.1mA increments.

HT-4200S

Test Type: AC/DC.

Max. Output Voltage: 3000Vac / 4200Vdc.

Leakage Current: 1-10mAac / 1-5mAdc, 0.1mA increments.

All Models

Ground Continuity: $0.08\Omega-1.50\Omega$, 0.01Ω increments, Defeatable.

Ground Cont. Min. Current: 100mA.

Breakdown Detect: Independent High Frequency Circuit (50KHz-500KHz).

Transformer Power: <500VA

Leakage Current Detect: Independent Low Frequency Circuit.

Ramp Time Range: 1-5 Seconds. Test Time Range: 1-60 Seconds.

Discharge Time: <7ms for AC, <1.3s for max DC at open circuit.

Display: 4 Digits LED Display.

Voltage Meter Accuracy: $\pm 2\%$. Leakage Accuracy: ± 0.1 mA.

Duty Cycle: 100%. Pass/Fail Repeatability: ±3%.

ELECTRICAL

Rated Input Voltage: 120Vac, ±10%, overvoltage cat 2, 0.5A.

Frequency: 60Hz.

Fuse: 1A, 250V, time delay, 5x20mm.

SAFETY

Safety Interlock: 2-pin terminal block on rear panel; shorted for operation. (Optional)

Output Voltage Indicator: Front panel meter directly connected to High Voltage.

Failure Indicator: Visual; provided by red LED's, Audible; provided by buzzer.

Test automatically terminated on failure

Test automatically terminated on failure.

OUTPUTS

NEMA 5-15R: High Voltage output for easy DUT connection (N/A on HT-4200S model).

RETURN: 4mm Socket (XEF-1RR), 1000V, CAT IV, 24A, Black.

H.V. OUTPUT: 4mm Socket, 5000V, Red.



COMPLIANCE WEST USA

The blue box that tests. And tests.

Environmental

Operating Temperature: 15-40°C.

Relative Humidity Range: 0-90% non-condensing.

Altitude: 0-300m.

Pollution Degree II (indoors, office/laboratory).

General

Dimensions: 9¼" Wide x 4¾" High x 10" Deep.

Weight: 11lbs approx.

Product Package: • HT-S Tester.

HT-S User Manual.

• Ground Test Lead, qty 2 for HT-4200S model.

H.V. Test Lead

Calibration Pin.

• Power Cord.

NIST traceable calibration certificate to ANSI Z540.

Calibration Data Copy.

Options

00-TL:	TestLink option. Allows connection with GF-30AC-T for Ground Bond Test.
00-TLC:	TestLink cableset for use with 00-TL.
00-RI:	Relay Interface/PLC Interface. Test signals through relay contacts/coils.
00-AR:	Auto reset on pass. Resets after passing test.
00-XI:	External Safety Interlock.
00-HAN-S:	Carrying handle kit.
80-100-001-E	Explorer Case with foam for shipping/transport.
80-100-001-P	Pelican Case with foam for shipping/transport.

> Images







HT-2000S HT-2800S HT-4200S

Rev 6.4

